



Used as cachepot



Used as pot with saucer



Warnings

- The entire range of products can be used indoors or outdoors.
- Do not position the product on an uneven or sloping surface; this will avoid uncontrolled movements.
- Keep the article away from heat sources.
- Products with straight walls made using the rotational moulding system may show some warping that could become more obvious if the pot is exposed to direct sunlight.

Cleaning instructions

- Clean with a wet sponge with water and a neutral cleaner.
- Wipe clean with a damp cloth.
- It is recommended to avoid using solvents.
- In a case very dirty, clean with euro3plast cleaner.

Attention: permanent exposure to sun may change the original colour.